



Release Notes

# MT48436 InfiniScale® IV Firmware

fw-IS4 Rev 7.2.400

Mellanox Technologies

© Copyright 2009. Mellanox Technologies, Inc. All Rights Reserved.

Mellanox Technologies, Inc.  
350 Oakmead Parkway, Suite 100  
Sunnyvale, CA 94085  
U.S.A.  
[www.mellanox.com](http://www.mellanox.com)

Tel: (408) 970-3400  
Fax: (408) 970-3403

Mellanox Technologies Ltd  
PO Box 586 Hermon Building  
Yokneam 20692  
Israel

Tel: +972-4-909-7200  
Fax: +972-4-959-3245

NOTE:

THIS INFORMATION IS PROVIDED BY MELLANOX FOR INFORMATIONAL PURPOSES ONLY AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL MELLANOX BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS HARDWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# 1 Overview

These are the release notes for the MT48436 InfiniScale® IV firmware fw-IS4, Rev 7.2.400. This firmware complements the InfiniScale IV MT48436 silicon architecture with a set of advanced features, allowing easy and remote management of the switch.

Note: After burning new firmware to the InfiniScale IV switch device, reboot the switch so that the new firmware can take effect.

This document includes the following sections:

- “Overview” (page 3)
  - “Notes on This Release” (page 3)
  - “Requirements” (page 3)
- “Changes and Major New Features” (page 3)
- “Unsupported Features” (page 3)
- “Bug Fixes” (page 4)
- “Known Issues” (page 4)
- “SMA/GSA Attributes” (page 5)
- “Firmware Initialization And Configuration (.INI) File” (page 8)
- “History of Bug Fixes” (page 20)

## 1.1 Notes on This Release

- This firmware release complies with the *InfiniScale IV MT48436 Programmer’s Reference Manual (PRM), Doc. #2885, Rev 0.23* or later.

## 1.2 Requirements

- One of the following burning tools:
  - **flint** or **mlxburn** applications (part of MFT ver. 2.5.0 or later)
- Burning firmware to the switch can be performed In-Band or via the I2C-compatible interface. Burning via the I2C-compatible interface requires one of the following I2C cards:
  - MTUSB-1 (USB to I2C adapter)
  - ISA Calibre

## 2 Changes and Major New Features

- Mellanox auto-negotiation:
  - Enhanced the sweep procedure to yield better eye measurements
  - Added an optional crosstalk reduction algorithm. Enabling this algorithm multiplies the auto-negotiation duration by 4.
- Command interface:
  - Updated the SET\_PORT command to allow for changing the node description

## 3 Unsupported Features

- Baseboard Management Agent (BMA)

## 4 Bug Fixes

None in this release.

## 5 Known Issues

Table 1 - Known Issues

Index	Issue	Description	Current Implemented Workaround in FW	Possible Workaround	Scheduled Release (fix)
1.	AUTOCONF_1X4X8X12X setting is not supported	AUTOCONF_1X4X8X12X setting for the [LINK_WIDTH] parameter width_supported_clusterX is not supported	NA	NA	A future firm-ware release
2.	Mellanox auto-negotiation does not support 12X links		NA	NA	NA
3.	LinkWidth in INI file cannot be specified using IB port numbers	LinkWidth INI settings must use HW port numbers	NA	NA	A future firm-ware release
4.	No M_Key check is performed for packets sent by the external SMA		NA	NA	Next release
5.	If IB Port 1 is configured as 1x SDR, the link may be unstable		NA	NA	Next release
6.	Temperature Sensing	a. TRAP is not implemented. b. If the over-temperature warning GPIO mode is set ( $wgm=1$ ), the GPIO cannot be cleared by MAD	NA	NA	Next release

## 6 SMA/GSA Attributes

The following tables summarize the attributes supported by the management agents provided in this release.

Table 2 - SMA Attributes

Attribute	Support
Notice	-
NodeDescription	+
NodeInfo	+
SwitchInfo	+
GUIDInfo	+
PortInfo	+
Partition Key Table	+
SLtoVLMappingTable	+
VLArbitration	+
LinearForwardingTable	+
RandomForwardingTable	-
MulticastForwardingTable	+
SMInfo	-
VendorDiag	-
LedInfo	-
PrivateLFTMap (VendorSpecific)	-
PrivateLFTAccess (VendorSpecific)	-
PrivateLFTTops (VendorSpecific)	-
AdaptiveRoutingInfo (VendorSpecific)	-
AdaptiveRoutingGroupTable (VendorSpecific)	-
AdaptiveRoutingLinearForwardingTable (VendorSpecific)	-
RemotePortMirroring (VendorSpecific)	+
TemperatureSensing (VendorSpecific)	+

Table 3 - Mandatory Performance Management Attributes

Attribute	Support
ClassPortInfo	+
PortSamplesControl	+
PortSamplesResult	+

Table 3 - Mandatory Performance Management Attributes (Continued)

Attribute	Support
PortCounters	+
PortCountersExtended (for data counters only)	+

Table 4 - Optional Performance Management Attributes

Attribute	Support
PortRcvErrorDetails	+
PortXmitDiscardDetails	+
PortOpRcvCounters	-
PortFlowCtlCounters	+
PortVLOpPackets	-
PortVLOpData	-
PortVLXmitFlowCtlUpdateErrors	+
PortVLXmitWaitCounters	+
PortCountersExtended	+
PortSamplesResultExtended	+
SwPortVLCongestion	+
PortXmitConCtrl	+
PortVLXmitTimeCong	-
PortXmitDataSL	+
PortRcvDataSL	+

Table 5 - VendorSpecific MADs

InfiniBand Management Class	Management Attribute	Supported by Last Release	Supported by New Release
0x0A VendorSpecific class	0x0001 ClassPortInfo	-	+
	0x0011 PortPowerState	-	-
	0x0012 DeviceSoftReset	+	+
	0x0013 ExtPortAccess	-	+
	0x0014 PhyConfig	-	+
	0x0015 MFT	-	-
	0x0017 GeneralInfo	-	+
	0x0050 ConfigSpaceAccess	+	+
	0x0060 PortRcvDataVL	-	+
	0x0061 PortXmitDataVL	-	+
	0x0062 PortRcvPktsVL	-	+
	0x0063 PortXmitPktsVL	-	+
	0x0068 FlowMonitoringCountersInfo	-	-
	0x0069 FlowMonitoringCounter	-	-
	0x0070 CongestionNotificationInfo	-	-
	0x0080 Virtual switch Info	-	-
	0x0090 CounterGroupInfo	-	+
	0x0091 ConfigCounterGroup	-	+
	0x00A0 EnhancedConfigSpaceAccess	-	-

## 7 Firmware Initialization And Configuration (.INI) File

Note: This section is intended for OEMs only.

The Mellanox firmware burning tools enable setting initialization and configuration attributes to suit a user's specific system by the use of a special (.INI) file. This section describes this user-supplied initialization and configuration file.

To begin with, the .INI file is a text file composed of several initialization and configuration *sections*. The user may choose to include all sections and all attribute settings in the final .INI file, and modify some of the attributes as required. Alternatively, the user may choose to keep only the sections with changes to the existing settings, with only those attributes that are to be modified.

This .INI file is described in the following sub-sections:

- “.INI File Format” on page 8
- “Description and Usage of .INI File Sections” on page 8

### 7.1 .INI File Format

The .INI file is actually a concatenation of (a part or all) section specific initialization and configuration settings. Each section in the .INI file starts with its name between square brackets, e.g. [PS\_INFO], [IB], [link\_speed], etc. The section name is followed by one or more lines of configuration settings and comments, as in the excerpt below from the .INI file of Mellanox Technologies' 36 QSFP IB QDR Port Switch. Note that comment lines start with a semicolon.

#### Example:

```
[PS_INFO]
Name = MTS3600Q-1UNC_A1
Description = MELLANOX SHARK QDR SWITCH 36QSFP PORTS WITH 1 PS UNMNG R5

[link_speed]
QDR_EN_port1 = true
QDR_EN_port2 = true
QDR_EN_port3 = true
QDR_EN_port4 = true
QDR_EN_port5 = true

[TX_REVERSE]
tx_lane_reversal_port1=On
tx_lane_reversal_port2=On
tx_lane_reversal_port3=On
tx_lane_reversal_port4=Off
tx_lane_reversal_port5=On

; End of .INI file
```

### 7.2 Description and Usage of .INI File Sections

Note: Refer to the `fw-IS4-defaults.ref` file for more details. This file is included in the firmware tarball provided under the Customized firmware downloads Web page (see <http://www.mellanox.com> under Firmware downloads).



The .INI file sections are:

1. [PS\_INFO] – see Section 7.2.1 on page 9
2. [ADAPTER] – see Section 7.2.2 on page 9
3. [NODE\_INFO] – see Section 7.2.3 on page 10
4. [IB] – see Section 7.2.4 on page 10
5. [SERDES] – see Section 7.2.5 on page 10
6. [LINK\_SPEED] – see Section 7.2.6 on page 11
7. [LINK\_WIDTH] – see Section 7.2.7 on page 12
8. [IB\_TO\_HW\_MAP] – see Section 7.2.8 on page 14
9. [VL\_CAP] – see Section 7.2.9 on page 15
10. [IB\_TO\_LED\_MAP] – see Section 7.2.10 on page 15
11. [TX\_REVERSE] – see Section 7.2.11 on page 17
12. [RX\_REVERSE] – see Section 7.2.12 on page 17
13. [POLARITY] – see Section 7.2.13 on page 18
14. [PORT\_DISABLE] – see Section 7.2.14 on page 18
15. [UNUSED\_PORTS] – see Section 7.2.15 on page 18
16. [EKEYING] – see Section 7.2.16 on page 19
17. [PLL] – see Section 7.2.17 on page 19
18. [GPIO] – see Section 7.2.18 on page 19
19. [FW] – see Section 7.2.19 on page 19

### 7.2.1 [PS\_INFO]

This section provides firmware configuration (ini) information used by the IB Administration tools. It has no impact on the generated firmware image.

#### Example:

Name = MTS3600Q-1UNC\_A1

Description = MELLANOX SHARK QDR SWITCH 36QSFP PORTS WITH 1 PS UNMNG R5

### 7.2.2 [ADAPTER]

This section provides product specific information such the following:

- PSID (parameter: PSID)  
On-switch adapter's firmware configuration ID. This attribute can be assigned a string built from up to 16 characters of the set: [A-Z,0-9].
- Vendor ID (parameter: adapter\_vendor\_id)  
This parameter holds the Vendor ID of Mellanox Technologies: 0x15b3. It is reported to a QUERY\_ADAPTER query by the driver.
- PCI Device ID and Revision ID (parameters: adapter\_dev\_id, adapter\_rev\_id)  
Used for identifying the switch over the PCI Express interface. They are reported to a QUERY\_ADAPTER query by the driver. Both are integer parameters in the range 0x0 to 0xffff.

**Example:**

```
PSID = MT_0C20110003
adapter_vendor_id = 0x15b3
adapter_dev_id = 0xbd34
adapter_rev_id = 0xa
```

**7.2.3 [NODE\_INFO]**

This section allows programming parameters such as SystemImageGUID, NodeGUID, and PortGUID.

**7.2.4 [IB]**

This section defines InfiniBand specific information of the product such as the Mellanox IB Vendor ID (parameter: nodeinfo\_vendor\_id), Partition Table size supported by each port (parameter: nodeinfo\_log\_partition\_cap), and others.

**Example:**

```
;;;; Mellanox IB Vendor ID. A part of the Node Information that may be queried by the
;;;; Subnet Manager (SM)
nodeinfo_vendor_id = 0x2c9

;;;; Log 2 of Partition Table size supported by each port.
;;;; Integer parameter. Values range : 0 - 7.
nodeinfo_log_partition_cap = 7
```

**7.2.5 [SERDES]**

This section configures the SerDes of all the switch InfiniBand ports. Each port can be set to one of 16 possible configurations per port speed (SDR/DDR/QDR). Each configuration is defined by the following parameter types: eye pointer parameters, Tx parameters, and Rx parameters.

**Tx parameters:**

1. ob\_preemp\_main - Range: 0x0-0x1f
2. ob\_preemp\_post - Range: 0x0-0x1f
3. ob\_preemp\_pre - Range: 0x0-0x1f
4. preemp\_mode - Range: 0x0-0x3

**Rx parameters:**

1. extra\_hs\_gain - Range: 0x0-0x7
2. equal - Range: 0x0-0x7f
3. muxmain - Range: 0x0-0x1f
4. muxeq - Range: 0x0-0x1f
5. main - Range: 0x0-0xf

By default, all ports are configured according to “generic” port parameters. Generic parameters have the following format:

```
{PARAM_NAME}_generic_{SPEED}_config{CONFIG_NUM}
```

where:

{PARAM\_NAME} is one of the SerDes parameters listed above;

{SPEED} is SDR, DDR, or QDR; and

{CONFIG\_NUM} is an integer from 1 to 16.

To override the generic port configuration for a specific port, use the port configuration enable parameter `en_serdes_conf_IbPortX` (possible values: TRUE, FALSE) as follows:

```
en_serdes_conf_IbPortX=TRUE    (X=1,2,...,36)
```

Port parameters are set using the following format:

```
{PARAM_NAME}_IbPort{PORT_NUM}_{SPEED}_config{CONFIG_NUM}
```

**Warning: It is not recommended to modify the SerDes parameters without consulting Mellanox Technologies as the parameters are set to standard and operational values by default.**

#### Example:

```
;;; Enable ports 1-5 for non-generic configuration
en_serdes_conf_IbPort1=TRUE
en_serdes_conf_IbPort2=TRUE
en_serdes_conf_IbPort3=TRUE
en_serdes_conf_IbPort4=TRUE
en_serdes_conf_IbPort5=TRUE

;;;; Integer parameter. Values range : 0x0 - 0x7.
extra_hs_gain_generic_SDR_config1 = 0x0
extra_hs_gain_generic_SDR_config2 = 0x0
extra_hs_gain_generic_SDR_config3 = 0x0
extra_hs_gain_generic_SDR_config4 = 0x0
extra_hs_gain_generic_SDR_config5 = 0x0
;;;; Integer parameter. Values range : 0x0 - 0x1f.
muxeq_generic_QDR_config1 = 0x0
muxeq_generic_QDR_config2 = 0x0
muxeq_generic_QDR_config3 = 0x0
muxeq_generic_QDR_config4 = 0x0
muxeq_generic_QDR_config5 = 0x0
ob_preemp_post_generic_QDR_config1 = 0x4
ob_preemp_post_generic_QDR_config2 = 0x4
ob_preemp_post_generic_QDR_config3 = 0x4
ob_preemp_post_generic_QDR_config4 = 0x4
ob_preemp_post_generic_QDR_config5 = 0x4
```

## 7.2.6 [LINK\_SPEED]

This section provides parameters for defining the maximum speed per port, and for enabling auto-negotiation of port speed. Table 7 lists and describes the parameters of this section and their possible configuration values.

Table 6 - Link Speed Parameters and Configuration Values

Parameter	Possible Configuration Values	Resulting Cluster Configuration
SPEC1_2_portX (X=1,2,...,36)	TRUE	The PHY is compliant with <a href="#">Release 1.2</a> of the InfiniBand Architecture Specification (specifically, the autonegotiation algorithm)
	FALSE	The PHY is <i>not</i> compliant with <a href="#">Release 1.2</a> of the InfiniBand Architecture Specification (specifically, the autonegotiation algorithm)
SDR_EN_portX (X=1,2,...,36)	TRUE	Sets bit 0 (SDR) of the <i>LinkSpeedEnabled</i> field of Port X. A PortInfo Set() MAD can override this value.  NOTE: This bit must be set to enable the Mellanox speed auto-negotiation algorithm for this port.
	FALSE	Clears bit 0 of the <i>LinkSpeedEnabled</i> field of Port X. This setting disables speed auto-negotiation for this port.
DDR_EN_portX (X=1,2,...,36)	TRUE	Sets bit 1 (DDR) of the <i>LinkSpeedEnabled</i> field of Port X. A PortInfo Set() MAD can override this value.
	FALSE	Clears bit 1 of the <i>LinkSpeedEnabled</i> field of Port X.
QDR_EN_portX (X=1,2,...,36)	TRUE	Sets bit 2 (QDR) of the <i>LinkSpeedEnabled</i> field of Port X. A PortInfo Set() MAD can override this value.
	FALSE	Clears bit 2 of the <i>LinkSpeedEnabled</i> field of Port X.
speed_supported_portX (X=1,2,...,36)	SDR	SDR is the only speed supported by HW for this port
	SDR_DDR	Both SDR and DDR speeds are supported by HW for this port
	SDR_DDR_QDR	SDR, DDR and QDR speeds are supported by HW for this port

### 7.2.7 [LINK\_WIDTH]

The 36 physical IB ports of the InfiniScale IV are viewed as twelve 3-port clusters. Each such cluster gets a single command line in the [LINK\_WIDTH] section to configure the link widths of its 3 ports. The configuration settings in this section determine both the LinkWidthSupported and the LINK\_WIDTH attributes of all InfiniScale IV ports during boot.

The clusters are numbered cluster1 through cluster12, and the ports are assigned to these clusters in an ascending order. Thus, cluster1 groups ports 1, 2, and 3; cluster2 groups ports 4, 5, and 6;..., cluster12 groups ports 34, 35, and 36.

Per cluster, there are two parameters to set in this section: the maximum width in SerDes lanes supported by the Subnet Manager for a cluster (*width\_enabled\_clusterX*, where X=1,2,...,12), and maximum width in SerDes lanes supported by the HW for a cluster (*width\_supported\_clusterX*, where X=1,2,...,12).

Table 7 describes the possible configuration values for the couples of cluster parameters.

Table 7 - Configuration Values for Cluster Port Link Widths

Parameter	Possible Configuration Values	Resulting Cluster Configuration
width_enabled_clusterX (X=1,2,...,12)	LIKE_WIDTH_SUPPORTED	If the Subnet Manager supports only configurations where all clusters have the same link width, set width_enabled_clusterX to LIKE_WIDTH_SUPPORTED for all the clusters, and choose the same value for width_supported_clusterX for all the clusters.
	X4	The Subnet Manager supports a maximum link width of 4 SerDes for clusterX
	X8	The Subnet Manager supports a maximum link width of 8 SerDes for clusterX
	X12	The Subnet Manager supports a maximum link width of 12 SerDes for clusterX
width_supported_clusterX (X=1,2,...,12)	TRIO_1X	The cluster is configured as 3 separate ports, each limited to 1X link width only
	TRIO_1X4X	The cluster is configured as 3 separate ports, each supporting 1X or 4X link width
	TRIO_4X	The cluster is configured as 3 separate ports, limited to 4X link width only
	SINGLE_1X <sup>1</sup>	The cluster is configured as a single port, limited to 1X link width only
	SINGLE_1X4X <sup>1</sup>	The cluster is configured as a single port supporting 1X and 4X link width
	SINGLE_1X4X8X <sup>1</sup>	The cluster is configured as a single port supporting 1X, 4X and 8X link width
	SINGLE_1X4X8X12X <sup>1</sup>	The cluster is configured as a single port supporting 1X, 4X, 8X, and 12X link widths
	AUTOCONF_1X4X8X12X	The cluster will auto-configure itself to match the configuration of the (peer) cluster connected to it through the IB cable

1. If width\_supported\_clusterX (X=1,2,...,12) is set to one of the values SINGLE\_1X, SINGLE\_1X4X, SINGLE\_1X4X8X, or SINGLE\_1X4X8X12X, then the three HW ports of the cluster must be mapped to the same logical IB port.

Note that in case a cluster is set as AUTOCONF\_1X4X12X, then it may rise as a single 12X port or as three 4X ports, depending on the peer cluster capabilities at the time of link bring-up. This may occur in every instance of bring-up. Thus the cluster may start out as three 4X ports prior to link (re)establishment, and turn into a single 12X port after (re)establishment, or vice versa.

#### Example:

```
width_enabled_cluster1 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster2 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster3 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster4 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster5 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster6 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster7 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster8 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster9 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster10 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster11 = LIKE_WIDTH_SUPPORTED
width_enabled_cluster12 = LIKE_WIDTH_SUPPORTED
```

```
width_supported_cluster1 = TRIO_1X4X
```

```

width_supported_cluster2 = TRIO_1X4X
width_supported_cluster3 = TRIO_1X4X
width_supported_cluster4 = TRIO_1X4X
width_supported_cluster5 = TRIO_1X4X
width_supported_cluster6 = TRIO_1X4X
width_supported_cluster7 = TRIO_1X4X
width_supported_cluster8 = TRIO_1X4X
width_supported_cluster9 = TRIO_1X4X
width_supported_cluster10 = TRIO_1X4X
width_supported_cluster11 = TRIO_1X4X
width_supported_cluster12 = TRIO_1X4X

```

### 7.2.7.1 Link Width Lockup

An IB port in a trio that is enabled for and configured to 4X width (4-SerDes port) by means of the `width_enabled_clusterX` and `width_supported_clusterX` parameters above may still be switched by the Subnet Manager to 1X width (1-SerDes port). To prevent this scenario, the user can enable the configuration parameter `Link_Width_Lockup`. This indicates to the Subnet Manager that a device port configured as a 4X port will *not* reconfigure to a 1X port even if asked to.

Possible values for the `Link_Width_Lockup` parameter are Disable (the default) and Enable.

Note: This mode of operation, where `Link_Width_Lockup` is enabled, serves as an extension to the functionalities defined in the *InfiniBand Architecture Specification (Release 1.2)*.


#### Example:

```
Link_Width_Lockup = Disable
```

### 7.2.8 [IB\_TO\_HW\_MAP]

This section maps the logical IB ports to the InfiniScale IV HW ports. The mapping is performed using the parameter `PORTX` ( $X=1,2,\dots,36$ ) that identify the logical ports. Each such port is assigned a HW port that is represented by an integer value in the range 1-36.

Figure 1: Mapping a Chassis Logical IB Port to a HW Port



Note: If `width_supported_clusterX` ( $X=1,2,\dots,12$ ) is set to one of the values `SINGLE_1X`, `SINGLE_1X4X`, `SINGLE_1X4X8X`, or `SINGLE_1X4X8X12X`, then the three HW ports of the cluster must be mapped to the same logical IB port.

#### Example:

```
[ IB_TO_HW_MAP ]  
PORT1 = 18  
PORT2 = ...  
...
```

### 7.2.9 [VL\_CAP]

This section is optionally used to set the

- maximum operational VLs for each port
- mode of credit allocation between port VLs

#### Maximum Operational VLs:

Each port can be configured to operate one of the following maximum number of VLs: max\_1\_vls (1 VL), max\_2\_vls (2 VLs), max\_4\_vls (4 VLs), or max\_8\_vls (8 VLs). By default, all ports are set to max\_8\_vls as follows:

```
PORT1 = max_8_vls  
PORT2 = max_8_vls  
...  
PORT35 = max_8_vls  
PORT36 = max_8_vls
```

Note that the actual number of Operational VLs per port is set by the Subnet Manager. For more details, see the section titled “Credit Allocation for Virtual Lanes” in the *MT48436 InfiniScale IV Programmer’s Reference Manual, Revision 0.21* or later, *Document no. 2849PM*.

#### Credit Allocation Mode:

The mode of credit allocation is set using the parameter Cred\_Alloc\_Mode. If this parameter is 0 (default), then credit allocation complies with the *InfiniBand Architecture Specification*: credits for a single MTU (2KB) packet are allocated for each VL numbered above  $2^{\text{OperationalVLs}-1}$  up to  $2^{\text{VLCap}-1}$ , and the remaining credits are allocated between the Operational VLs according to the InfiniScale IV scheme of credit allocation. For more details, see the section titled “Credit Allocation for Virtual Lanes” in the *MT48436 InfiniScale IV Programmer’s Reference Manual, Revision 0.21* or later, *Document no. 2849PM*.

If Cred\_Alloc\_Mode is 1, credits are allocated to the Operational VLs only according to the InfiniScale IV scheme of credit allocation. VLs numbered above  $2^{\text{OperationalVLs}-1}$  receive no credits at all.

Note: This mode (Cred\_Alloc\_Mode=1) is *not* compliant with the *InfiniBand Architecture Specification*.

### 7.2.10 [IB\_TO\_LED\_MAP]

The InfiniScale IV implements a built-in link indicator controller. The controller controls the status of 36 Yellow-Green LED pairs assigned to each InfiniBand port of the switch. The Green LED provides an indication on the physical link state. When this LED is lit then the physical link is up. The Yellow LED indicates that the logical link is up, and its blinking rate indicates link activity.

The LEDs status is controlled through the pins LED\_DATA[7:0] and LED\_CLK[4:0] of the InfiniScale IV. Using the firmware configuration (.INI) file, the user can map each of the InfiniScale IV ports to a pair of consecutive

LED\_DATA lines (one for a Green LED and another for a Yellow LED) as specified in Table 8. Each of the LED\_CLK signals controls the LED\_DATA pairs of eight 4X ports.

Table 8 - Link Indicators Control Pins Summary

Pin Name	Function	Relevant .INI Parameter Name or Value
LED_DATA0	Green LED status of Port <i>i</i>	IB <sub><i>i</i></sub> _led_pair = pair1_0
LED_DATA1	Yellow LED status of Port <i>i</i>	IB <sub><i>i</i></sub> _led_pair = pair1_0
LED_DATA2	Green LED status of Port <i>j</i>	IB <sub><i>j</i></sub> _led_pair = pair3_2
LED_DATA3	Yellow LED status of Port <i>j</i>	IB <sub><i>j</i></sub> _led_pair = pair3_2
LED_DATA4	Green LED status of Port <i>k</i>	IB <sub><i>k</i></sub> _led_pair = pair5_4
LED_DATA5	Yellow LED status of Port <i>k</i>	IB <sub><i>k</i></sub> _led_pair = pair5_4
LED_DATA6	Green LED status of Port <i>l</i>	IB <sub><i>l</i></sub> _led_pair = pair7_6
LED_DATA7	Yellow LED status of Port <i>l</i>	IB <sub><i>l</i></sub> _led_pair = pair7_6
LED_CLK0	On its rising edge, acts as Load Enable for the Green and Yellow LEDs of a set of four ports. On its falling edge, acts as Load Enable for the Green and Yellow LEDs of another set of four ports.	IBX_led_clock_sel=0 for rising IBX_led_clock_sel=5 for falling
LED_CLK1	On its rising edge, acts as Load Enable for the Green and Yellow LEDs of a set of four ports. On its falling edge, acts as Load Enable for the Green and Yellow LEDs of another set of four ports.	IBX_led_clock_sel=1 for rising IBX_led_clock_sel=6 for falling
LED_CLK2	On its rising edge, acts as Load Enable for the Green and Yellow LEDs of a set of four ports. On its falling edge, acts as Load Enable for the Green and Yellow LEDs of another set of four ports.	IBX_led_clock_sel=2 for rising IBX_led_clock_sel=7 for falling
LED_CLK3	On its rising edge, acts as Load Enable for the Green and Yellow LEDs of a set of four ports. On its falling edge, acts as Load Enable for the Green and Yellow LEDs of another set of four ports.	IBX_led_clock_sel=3 for rising IBX_led_clock_sel=8 for falling
LED_CLK4	On its rising edge, acts as Load Enable for the Green and Yellow LEDs of a set of four ports. On its falling edge, acts as Load Enable for the Green and Yellow LEDs of another set of four ports.	IBX_led_clock_sel=4 for rising IBX_led_clock_sel=9 for falling

Using the IB\_TO\_LED\_MAP section, each port is assigned to a LED\_CLK signal and to a LED\_DATA pair through the following parameters and settings:

IBX\_led\_clock\_sel = <number in the range 0-9> (X=1,2,...,36)

IBX\_led\_pair = < pair1\_0 | pair3\_2 | pair5\_4 | pair7\_6 >

where:

X=1,2,...,36

pair1\_0 indicates LED\_DATA1 and LED\_DATA0

pair3\_2 indicates LED\_DATA3 and LED\_DATA2

pair1\_0 indicates LED\_DATA5 and LED\_DATA4

pair3\_2 indicates LED\_DATA7 and LED\_DATA6



### 7.2.11 [TX\_REVERSE]

The transmit (Tx) SerDes of all IB ports support lane reversal. To configure the transmit SerDes of a port for lane reversal or no reversal, set the `tx_lane_reversal_portX` ( $X=1,2,\dots,36$ ) parameter to *on* or *off*, respectively.

**Example:**

```
tx_lane_reversal_port1 = on
tx_lane_reversal_port2 = on
```

The `tx_lane_reversal_autoflag_portX` parameters enable or disable dynamic Tx lane reversal, i.e., turning reversal on/off during operation.

**Example:**

```
tx_lane_reversal_autoflag_port1 = Off
tx_lane_reversal_autoflag_port2 = Off
```

It is also possible to enable or disable Tx lane reversal within a cluster using the `tx_rev_lane_IbClusterX` parameter ( $X=1,2,\dots,36$ ). Possible parameter values are: *on* for enabling reversal and *off* for disabling reversal.

**Example:**

```
tx_rev_lane_IbCluster1 = Off
tx_rev_lane_IbCluster2 = Off
tx_rev_lane_IbCluster3 = Off
```

### 7.2.12 [RX\_REVERSE]

The receive (Rx) SerDes of all IB ports support lane reversal. To configure the Rx SerDes of a port for lane reversal or no reversal, or for auto-configuration, set the `rx_lane_reversal_portX` ( $X=1,2,\dots,36$ ) parameter to *on* or *off* or *auto*, respectively.

**Example:**

```
rx_lane_reversal_port1 = auto
rx_lane_reversal_port2 = auto
rx_lane_reversal_port3 = auto
rx_lane_reversal_port4 = off
rx_lane_reversal_port5 = off
rx_lane_reversal_port6 = off
```

It is also possible to enable, disable, or allow auto-configuration for Rx lane reversal within a cluster using the `rx_rev_lane_IbClusterX` parameter ( $X=1,2,\dots,36$ ). Possible parameter values are: *on* for enabling reversal; *off* for disabling reversal; and *auto* for allowing auto-configuration.

**Example:**

```
rx_rev_lane_IbCluster1 = auto
tx_rev_lane_IbCluster2 = Off
```

```
tx_rev_lane_IbCluster3 = Off
```

### 7.2.13 [POLARITY]

The InfiniScale IV hardware supports Tx and Rx SerDes (lane) polarity reversal for both Tx and Rx. By default, Tx and Rx SerDes polarity reversal is disabled.

#### 7.2.13.1 Tx SerDes Polarity

Use the `tx_lane_polarity_portX` ( $X=1,2,\dots,36$ ) parameter to set the polarity of the Tx lanes within a 4X port. This parameter takes a 4-bit value between 0x0-0xf (0-15 decimal), with a 1 at bit  $i$  ( $i=0,1,2,3$ ) indicates polarity reversal for lane  $i$  and a 0 indicates no polarity reversal.

##### Example:

```
;; No polarity reversal on Port 1 Tx lanes
tx_lane_polarity_port1=0x0
;; Polarity reversal on Tx lanes 0 and 1 of Port 1
tx_lane_polarity_port1=0x3
```

#### 7.2.13.2 Rx SerDes Polarity

Use the `rx_lane_polarity_portX` ( $X=1,2,\dots,36$ ) parameter to set the polarity of the Rx lanes within a 4X port. This parameter takes a 4-bit value between 0x0-0xf (0-15 decimal), with a 1 at bit  $i$  ( $i=0,1,2,3$ ) indicates polarity reversal for lane  $i$  and a 0 indicates no polarity reversal.

##### Example:

```
;; No polarity reversal on Port 1 Rx lanes
rx_lane_polarity_port1=0x0
;; Polarity reversal on Rx lanes 0 and 1 of Port 1
rx_lane_polarity_port1=0x3
```

It is also possible to fix the Rx lanes polarity of a port (to prevent dynamic changes to polarity) using the `rx_force_polarity_portX` ( $X=1,2,\dots,36$ ) parameter. By default, Rx lane polarity is not fixed (`rx_force_polarity_portX=Disable`). To fix the Rx lanes polarity, set the parameter value to Enable.

##### Example:

```
rx_force_polarity_port1=Enable
rx_force_polarity_port2=Disable
```

### 7.2.14 [PORT\_DISABLE]

By default, the initial state of all physical ports is Polling. This section provides the parameter `disable_portX` ( $X=1,2,\dots,36$ ) for changing the initial state to Disable. The parameter has two possible values: TRUE or FALSE

##### Example:

```
disable_port1 = false
disable_port2 = false
```

### 7.2.15 [UNUSED\_PORTS]

This section allows automatic shutdown of unused ports. This is provided via the `hw_portX_not_in_use` parameter ( $X=1,2,\dots,36$ ). Set `hw_portX_not_in_use` to TRUE to enable automatic shutdown for an unused port, or set it to FALSE to prevent automatic shutdown for an unused port.

**Example:**

```
hw_port1_not_in_use = false
hw_port2_not_in_use = false
```

**7.2.16 [EKEYING]**

The InfiniScale IV supports port ekeying. Specifically, it allows electronic keying to shut down a port in case a protocol other than InfiniBand is attempted on the port connection. Use the `hw_port1_support_ekeying` parameter to disable (FALSE) or enable (TRUE) port ekeying. By default, port ekeying is disabled.

**Example:**

```
hw_port1_support_ekeying = true
hw_port2_support_ekeying = false
```

**7.2.17 [PLL]**

This section provides parameters for PLL debug. It is intended for internal use.

**7.2.18 [GPIO]**

This section provides parameters for setting special functionality for select GPIO pins.

By default, all GPIO pins are initially set as *inputs*. This is equal to setting the `gpio_mode` parameter to 0. Setting this parameter to 1 configures the GPIO pins as outputs.

**Example:**

```
gpio_mode = 0x0
```

**7.2.19 [FW]**

Use this section to set parameters relevant to the on-board Flash devices and their management.

To indicate the size of a single Flash device in bytes, enter its binary logarithm value (in the range 0-24).

**Example:**

```
;; Flash device size is 2 MBytes
log_flashdev_size = 21
```

## 8 History of Bug Fixes

### 8.1 FW Version 7.1.000 Bug Fixes

N/A (first release of firmware)

### 8.2 FW Version 7.2.000 Bug Fixes

Table 9 - FW Version 7.2.000 Bug Fixes

Index	Issue	Description
1.	Cannot set VL_CAP by ini	Fixed (ID: 52924)
2.	Non- qp0/qp1 packets to the SMA of an unmanaged switch hang the FW	Fixed (ID: 54031)
3.	PKEY: Inbound P_Key Enforcement partial bit is set by default instead of cleared	Fixed (ID: 54030)
4.	Symbol error counter of IB Port1 is not cleared after boot	Fixed
5.	Mellanox auto-negotiation ini parameters	ini values of auto-negotiation iteration 15 and 16 were ignored (all values set to zero)
6.	PortCounters MAD: Cannot clear PortXmitWait counter using set()	Added PortXmitWait bit in the <i>counterselect2</i> field (As per IBTA comment MGTWG2276-NEW) (ID: 55888)
7.	Wrong capability mask in ClassPortInfo of performance management class	Fixed
8.	Mellanox auto-negotiation: If NOI/NRI of peer device is higher than InfiniScale IV NOI/NRI values, SerDes parameters may all be set to zero	Fixed
9.	Secondary I2C address conflicts with temperature sensor I2C address on Shark system	Changed the default secondary I2C slave address to 0x68 (used to be 0x48)
10.	Cannot use MAD to open a port disabled by INI file	It is now possible to use a PortInfo MAD to open a port that was disabled by the <i>port_disable</i> parameter in the INI file

### 8.3 FW Version 7.2.100 Bug Fixes (Intermediate Release)

Table 10 - FW Version 7.2.100 Bug Fixes

Index	Issue	Description
1.	command interface - using MAD_IFC causes unexpected behavior	Fixed
2.	command interface - QUERY_FW does not support OpMod=0x2	Fixed
3.	command interface - INIT_PORT and CLOSE_PORT are not supported	Fixed
4.	command interface - bit BM in INIT_MAD_DEMUX is not supported	Fixed
5.	HCA driver interface: HW2SW_DQ may post extra CQEs	Fixed

### 8.4 FW Version 7.2.200 Bug Fixes (Intermediate Release)

Table 11 - FW Version 7.2.200 Bug Fixes

Index	Issue	Description
1.	Overtemp warning GPIO cannot be set	The GPIO indicating the overtemp warning cannot be set because the support bit is missing in the ini file. Status: Fixed

Mellanox Technologies